

Amplicon Generic Recovery Disk Instructions

The Amplicon Recovery DVD has been supplied solely to facilitate the recovery of a single PC system and should not be used with any other system or device without our permission. If you require additional recovery disks, you must contact the Amplicon Support Team.

This Generic disk includes all the drivers for the motherboard or single board computer and has been resealed using the Microsoft Sysprep utility. It does not include drivers for additional plug-in cards, or customer specific software or settings. You will need to run through a limited setup procedure before you can start using the machine. During this process you will need to enter the OEM key displayed on the Windows Licence Sticker and also run through Windows Activation. After the setup is complete, you will be able to install any required additional drivers or software.


Recovery process

WARNING – THE RECOVERY DISK WILL WIPE ALL DATA AND SET THE MACHINE BACK TO FACTORY DEFAULT.


Enter the PC BIOS screen by pressing either the **Delete** or **F2** key (this varies between hardware) as the machine boots. Set the first boot device to the DVD drive. Insert the Recovery DVD and let the machine start up.




1. The Amplicon Recovery Disc will load and take a few moments to detect the hardware



2. To accept the disk wipe and recovery type "Y". Typing "N" will reboot the system



3. Amplicon Recovery Disc will now start the image recovery showing a percentile of completion



4. When the recovery process is complete you will be prompted to remove the disk. Press any key to reboot the system